



# PRESETS FOR 3X, 3XW, 10X, 20X AND 30X

V1.0

Setting a preset for the HuddleCamHD

## Setting a Preset:

1. Start by making sure the camera is powered and the USB connection has been established
2. Navigate the camera to the position you wish to create a preset for
3. Click on the preset number you wish to assign [1-9] to the current location
4. Click on the “Set” button

## Calling a Preset:

1. Start by making sure the camera is powered and the USB connection has been established
2. Click on the preset number you wish to call [1-9]
3. Click on the “Call” button
4. The camera will move to the requested preset location

## Clearing a Preset:

*Please note that you can ALWAYS set a preset over an existing preset; however if you truly wish to clear a preset button follow the steps below*

1. Start by making sure the camera is powered and the USB connection has been established
2. Click on the preset number you wish to clear [1-9]
3. Click on the “Clear” button

