



CHANGING THE RESOLUTION FOR YOUR HUDDLECAMHD

V1.2

HOW-TO

1. Connect HuddleCamHD USB cable to the USB port on the HuddleCamHD
2. Connect the USB cable from the HuddleCamHD to the USB port on the computer
3. Connect the power supply to the nearest outlet
4. Plug the power cable into the power port on the HuddleCamHD
5. Wait for the camera “boot-up” sequence where the head of the camera will Pan, Tilt and Zoom
6. Open the AMCAP software
 - a. Click on the “Devices” menu
 - b. Select the HuddleCamHD, possibly labeled “USB Camera” or “USB3 Camera”
 - c. You should now be seeing you HuddleCamHD in the preview window
 - d. Click on the “Options” menu and select “Video Capture Pin”
 - i. Make sure the “Output Size” is set to “1280 x 720” or “1920 x 1080”
 - ii. Click “OK”
7. That is all you need to do

